Table 1: European (CENELEC) and US Programme type codes				
Number	**CENELEC PTY (RDS)**		**US PTY (RBDS)**	
0	No programme type or undefined	NONE	No programme type	__****__
1	News	NEWS	News	NEWS
2	Current affairs	AFFAIRS	Information	INFORM
3	Information	INFO	Sports	SPORTS
4	Sport	SPORT	Talk	TALK
5	Education	EDUCATE	Rock	ROCK
6	Drama	DRAMA	Classic rock	CLS_ROCK
7	Culture	CULTURE	Adult hits	ADLT_HIT
8	Science	SCIENCE	Soft rock	SOFT_RCK
9	Varied	VARIED	Top 40	TOP_40
10	Pop music	POP_M	Country	COUNTRY
11	Rock music	ROCK_M	Oldies	OLDIES
12	M.O.R. music	M.O.R._M	Soft	SOFT
13	Light classical	LIGHT_M	Nostalgia	NOSTALGA
14	Serious classical	CLASSICS	Jazz	JAZZ
15	Other music	OTHER_M	Classical	CLASSICL
16	Spare		R&B	R_&_B
17	Spare		Soft R&B	SOFT_R&B
18	Spare		Language	LANGUAGE
19	Spare		Religious music	REL_MUSIC
20	Spare		Religious talk	REL_TALK
21	Spare		Personality	PERSNLTY
22	Spare		Public	PUBLIC
23-29	Spares		Spares	
30	Spare		Emergency test	TEST
31	Alarm	ALARM	Emergency	ALERT!

Note: The texts at the right of each column are recommended for use on eight character receiver displays; "_" indicates a space